

MD Enterprises – Makers of Pro Panels

9017 Diplomacy Row • Dallas, TX 75247
800-525-4159 questions@propanels.com

Knock Down/Space Saver Panels

There are two sections to each panel. The lower section is identified by the Pro Panels label and screw out levelers in the legs. The other piece is the upper section.

1. Get 4 metal Couplers and 1 leather Connector.
2. Stand up 2 lower sections with their edges together in a loose V shape.
3. Insert 1 Coupler into each of the 4 holes on the top of the bottoms pieces.
4. Where the 2 bottoms meet up, there will be 2 Couplers side-by-side. Take the leather Connector and press it down over the 2 Couplers.
5. Fasten the included strap fastener on the bottom to hold the legs together.
6. Proceed with all the lower sections until they are complete and in the position you want.
7. Now put all of your top pieces on by sliding them down over the Couplers and wrapping the included strap fasteners around the posts on top.

If the round pipe that the couplers drop into becomes bent and you're having difficulty inserting the Couplers in, it is easy to make them round again by inserting a long screw driver inside the pipe and using leverage to push them back into place.

For an instructional video showing how to do this, as well as a video of how to set up the Knock Down panels, download a free QR reader app on your smartphone and scan these codes.

