

# MD Enterprises – Makers of Pro Panels

9017 Diplomacy Row • Dallas, TX 75247  
800-525-4159 [questions@propanels.com](mailto:questions@propanels.com)

---

## PRINT BIN

1. Pull the bin out of the box with the two side panels facing towards you.
2. Swing the side panels open to stand the base up on it's own.
3. Take the ends of the 2 poles that are attached to the sling and insert them into the holes on the back ends of the side panels.
4. Make sure the sides are pushed all the way in behind the front so when looking at the bin from the front, the sides aren't protruding out.
5. Inside the sling you'll find the L Braces for the front corners.

For an instructional video, download a free QR reader app on your smartphone and scan this code.

