

# MD Enterprises – Makers of Pro Panels

9017 Diplomacy Row • Dallas, TX 75247  
800-525-4159 [questions@propanels.com](mailto:questions@propanels.com)

---

## LIGHTING

1. On one side of the track there is an indented line, which is at the bottom (see photo below). Face the track with that line towards you. (You should be able to read the caution label on the inside).
2. Unscrew the cap on the **left end only** of the track and remove. With the black side of the cord end facing up, insert it into the open end of the track and tighten the screw to hold into place.
3. The cord end includes an optional on/off switch, which you can install. We do not recommend using it, as incorrect installation could cause the cord end not to work.



4. On the base of the light fixture there are two metal prongs facing one direction and one metal prong facing the other direction. Insert the fixture into the track and turn 90° so that the side with the two prongs turns towards the bottom (side with the indented line). Do not slide the fixture in from the end. Place the fixture directly into the spot you'd like it to go. The LED bulbs simply screw into the fixture.
5. To remove a fixture, pull the collar away from the track and turn 90° in either direction.



**When tearing down, we recommend removing the fixtures from the track, but keeping the bulbs screwed into the fixtures. This prevents wear and tear on the fixture over time.**

**For an instructional video, download a free QR Reader app on your smartphone and scan this code.**

